


**Scorpio rates for 2025-2026**

SL. No	Description of Item (2)	
		<b>Kuenzom Automobile Workshop</b>
1	SCORPIO	0
2	VEHICLE PARTS	0
3	Air Filter	747
4	Acelarator cable	247
5	Arm Bush Lower	347
6	Arm Bush upper	4277
7	Arm Steering Knuckle	12577
8	Arm Sub-Assy Pitman	1477
9	Axle Cone (Rear)	347
10	Axel Oil Seal	127
11	Axel Packing	47
12	Back Light Bulb	47
13	Ball Joint Upper	1247
14	Ball Joint Lower	1377
15	Battery	8977
16	Bearing Center support	247
17	Bearing Different Inner	1277
18	Bearing Diff. Side Gear	1247
19	Bearing Fronnt Wheel Inner	2257
20	Bearing Front Wheel Outer	1977
21	Bearing Rear Axle/Wheel	2977
22	Bearing Set Connecting Rod	977
23	Bearing Set Crankshalft	477
24	Bearing Tall Pinion Outer	377
25	Brake Booster Assy	12977
26	Brake Light Bulb (Double Point)	97
27	Brake Pad	6277
28	Brake Shoe Rear	5277
29	Bumper Light Assy (Front)	47
30	Bush Front Suspension (Lower LH)	677
31	Bush Front Suspension (Lower RH)	777






32	Bush Front Suspension (Upper RH/LH)	97
33	Bush Rear Stabiliser	147
34	Cam Shaft Bearing	977
35	Cam Bearing	677
36	Cap Assy. Fuel Filter	677
37	Center Bolt	97
38	Clutch Plate	5277
39	Clutch release Bearing	1977
40	Bendix Pinion	3277
41	Cross Bearing	987
42	CV Joint (Outer)	6277
43	CV Joint (Inner)	5277
44	Cylinder Assy brake master	2257
45	Cylinder Assy clutch master	1977
46	Cylinder Kit Brake master	547
47	Cylinder Kit clutch Master	657
48	Cylinder Kit Front Disc Brake	347
49	Cylinder Kit Rear wheel	577
50	Deliver Valve	157
51	Diesel Filter	157
52	Dust Guard	577
53	End Sub Assy Tie Rod (LH)	1277
54	End Sub Assy Tie Rod (RH)	1277
55	Engine Liner	977
56	Fan Belt	147
57	Fan Sub-Assembly	247
58	Fly Ring Gear	247
59	Fog Lamp	1277
60	Foot Stand	1247
61	Four Wheel Bearing	1247
62	Front Wheel Check Nut	147
63	Front Wheel Check Nut Lock	147
64	Fuel Filter	1247
65	Fuel Tank	0






66	Gasket Engine Overhaul	3277
67	Glass Back Light Assy LH/RH	147
68	Glass Back Light LH/RH	557
69	Glass Front Indicator LH/RH	47
70	Glow Plug	1177
71	Grille Radiater (Black)Show	2177
72	Grille Radiater (Chrompated)	577
73	Hand Brake Cable (Front)	1247
74	Hand Brake Cable(Rear)	547
75	Head and Rotor	0
76	Head Gasket	2677
77	Head lamp 3 pin	147
78	Head Lamp Assembly	4277
79	Horn	1267
80	Indicator/Side Light bulb	47
81	Injector Nozzle	0
82	Kilometer Cable	677
83	Kin Pin Bearing	1277
84	Kin Pin Sim	157
85	Lamp assy Front Bumper LH	437
86	Lamp Assy Front Bumper RH	437
87	Lens Front Indicator/side Light LH	97
88	Lens Front Indicator/Side Light RH	97
89	Link Rod Washer	347
90	Lifter Valve	247
91	Main Bearing Oil Seal	987
92	Mirror LH/RH	677
93	Oil Filter	977
94	Oil Pump Gear Inner	1367
95	Oil Pump Gear Outer	0
96	Oil Seal Cam Shaft	677
97	Oil Seal engine rear	127
98	oil Seal Front axle inner	57
99	Oil Seal Front Hub Outer	247






100	Oil seal Oil Axle Outer	47
101	Oil Seal Rear Inner	347
102	Oil Seal Tail Pinion	477
103	Oil Seal Valve Stem	197
104	Piston Ring	377
105	Power Steering Oil	10
106	Power Steering Pump	197
107	Pressure Plate	197
108	Pump Service Kit	1247
109	Radiator Cap	477
110	Radiator Assembly	12977
111	Rain Guard	2247
112	Rear View mirror	1277
113	Relay Glow Plug	247
114	Release Bearing	677
115	Seal oil Timing Gear case	677
116	Self Starter Armature	97
117	Shock Absorber	0
118	Shock Absorber Bush (Front)	7
119	Shock Absorber Front	1257
120	Shock Absorber Rear	1277
121	Shock Bush Lower/Upper	477
122	Shocker Washer	247
123	Silencer Assy	1277
124	Silencer Pipe Holder Bush	357
125	Solenoid Switch (self)	977
126	Spacer Rear Axle Bearing	247
127	Spring Bush Front - Rubber	357
128	Spring Front Leaf 2nd	1977
129	Spring Front Leaf 3rd	1297
130	Spring Front Leaf 4th	47
131	Spring Front Leaf 5th	147
132	Spring Metal Bush	147
133	Spring Front Leaf Main	347
134	Spring Mountain	357
135	Spring Rear Leaf 2nd	977
136	Spring Rear Leaf 3rd	2277
137	Spring Rear Leaf 4th	2177






138	Spring Rear Leaf 5th	1477
139	Spring Rear Leaf Main	2677
140	Stabilizer Link Bush	147
141	Stabilizer Link Rod	477
142	Stablizer Bush D type	157
143	Steering Damper	1247
144	Steering Knuckle Kit	367
145	Steering Rack Assembly	12677
146	Steering Rod	3217
147	Steering Yoke	1257
148	Suspension Arm Upper	1257
149	Suspension Arm Lower	1277
150	Thermostat Valve	1277
151	Thrust Washer	247
152	Tierod End	367
153	Timing Belt	247
154	Top sharp oil seal	147
155	Valve Exhaust	347
156	Valve External	367
157	Valve Guide	147
158	Valve Inlet	147
159	Valve Inner	7
160	Valve Seal	147
161	Valve Stem	277
162	Voltage Regulator	2247
163	Water Pump Assembly	4277
164	Wheel Drum	3277
165	Wheel Nut and Bolts (Front/Rear)	247
166	Wind Shields Glass	6277
167	Wiper Arm	7
168	Wiper Motor	477
169	Wiper Blade	0
170	Wiper Tank Motor	477
171	Extra Accessories	0
172	Brake Oil Dot 3 (350 ml)	477
173	Anabond Gum	97
174	Cloth	10
175	Coolant (per liter)	247
176	Dash Board Polish	337






177	Distilled Water	37
178	Engine Oil	407
179	Gear Box Oil Seal	777
180	Gear Oil	387
181	Grease	347
182	Power Steering Oil	477
183	Rope	7
184	Tail and Pinum Gear (Set) (4 Wheel) Front	0
185	Disel Filter	0
186	Seat Cover (Set)	9777
		237951

Service	Description of Services	
		<b>Kuenzom Automobile Workshop</b>
1	SCORPIO	0
2	Labour Charges (General)	0
3	Water Servicing and Air Servicing	447
4	Air Filter changing	7
5	Cam Shaft Oil Seal changing	247
6	Crank Shaft Grinding	2777
7	Engine Block Boring	2277
8	Engine Cleaning	7
9	Engine Head Removing and Refitting	2377
10	Engine Oil & Filter changing	297
11	Engine Overhauling 4 Cylinder Engine	2377
12	Engine Overhauling 6 Cylinder Engine	0
13	Engine Turning	1247
14	FIT Overhauling	0
15	Fuel Filter changing	247
16	Glow Plug changing	477
17	Head Gasket changing	1277
18	Main Bearing Oil Seal changing	377






19	Oil Pressure Switch changing	7
20	Oil Pump Gear changing	7
21	Piston Ring changing	477
22	Radiator Servicing (Removing & Refetting)	877
23	Replacement of Radiator Hose	147
24	Replacement of Thermostat Valve	7
25	Replacement of Fan Belt	197
26	Replacement of Injector Nozzle	377
27	Spark Plug changing or Servicing each	0
28	Tappet Adjustment	7
29	Tappet Cover Gasket changing	677
30	Timing Belt changing	677
31	Timing Gear Cover Oil Seal changing	97
32	Valve Facing each valve	77
33	Water Pump overhauling	97
34	Labour Charges (Electrical System)	0
35	Alternator Removing and Refitting/Overhauling	477
36	Alternator Repairing	997
37	Back Light changing each	7
38	Battery changing	7
39	C.B Point changing	0
40	changing of Head Light Bulb	7
41	Complete Electrical Wire Check Up	0
42	Cut Out Adjustment	7
43	Dynamo Armature Rewinding	777
44	Dynamo Overhauling	977
45	Fog Light New Fitting	147
46	Head Light Bulb changing each	7
47	Head Light changing each	47






48	Horn Adjustment/Fitting	97
49	Ignition Coil changing	0
50	Indicator Assembly changing each	0
51	Indicator Bulb changing	7
52	Indicator Glass changing each	0
53	Replacement of Electrical Switches	97
54	Replacement of Relays	47
55	Roof Lamp Bulb changing	7
56	Self Armature Rewinding	177
57	Self Starter Overhauling	147
58	Self Starter Removing and Refitting	747
59	Self Starter Repairing	977
60	Side Light Fitting	7
61	Wiper Arm and Blade changing	7
62	. Labour Charges (Steering Portion)	0
63	Kingpin Overhauling (one side)	7
64	Knuckle Oil Sealing changing	7
65	Power Steering Overhauling	777
66	Replacement of Pitman Arm	7
67	Steering Box Overhauling	377
68	Steering Yoke changing	7
69	Tid Rod End changing	297
70	Tube Repairing/Patching	197
71	Tyre Opening and Fitting	197
72	Wheel Alignment	397
73	Labour Charges (Transmission Portion)	0
74	Removing & Fitting of Spring Assy	677
75	Centre Bearing changing	7
76	Clutch Master Cylinder Kit changing	127






77	Clutch Master Cylinder Assembly changing	147
78	Clutch Plate changing	977
79	Cross Bearing Replacement each	477
80	Crown and Tail Fitting	1149
81	Differentail Overhauling/Remvoing & Refitting	1277
82	Fly Wheel Bearing changing	147
83	Front Axle Oil Seal changing each wheel	197
84	Front Hub Oil Seal changing each wheel	197
85	Front Wheel Bearing changing	477
86	Gear Box Overhauling	1197
87	Gear Oil changing	177
88	Nipple Greasing with Grease	477
89	Hubs Greasing per wheel	377
90	Knuckle Oil changing	0
91	Pressure Plate changing	1277
92	Propeller Shaft Bolt Replacement	147
93	Properller Shaft Cross Bearing changing each	147
94	Rear Axle Oil Seal changing and Greasing each	197
95	Rear Hub Oil Seal changing each wheel	147
96	Release Bearing changing	977
97	Gear Box removing and refitting	2277
98	Spring Bush changing complet	477
99	Spring Leafs changing	277
100	Tail Pinion Bearing changing	177
101	Tail Pinion Oil Seal changing	147





102	Wheel Bolt changing each wheel	127
103	Labour Charges (Brake Portion)	0
104	Adjustment of brake (one each)	127
105	Brake Booster Assembly changing	127
106	Brake Booster Kit changing	127
107	Brake Disc removing and refitting	477
108	Brake Disc turning/ facing	947
109	Brake Drum turning	947
110	Brake Lining changing	7
111	Brake Pad changing (1 side)	277
112	Brake Servicing each wheel	177
113	Brake Shoe changing rear wheel	197
114	Brake Master Cylinder changing	177
115	Brake Master Cylinder repair kit changing	127
116	Front Brake Calpier Kit changing	97
117	Gas Welding (per inch)	97
118	Hoot Stitching	0
119	Master Cylinder Assembly changing	47
120	Master Cylinder Kit changing	47
121	Number Plate Writing	377
122	Wheel Cyclinder	2977
123	W.C Kit changing each wheel front	7
124	Wheel Bearing changing and fitting	197
125	Wheel Bearing Rear changing	197
126	Break Light Assymby	7





127	Labour Charges (Suspension Syetem)	0
128	Coil Spring changing	7
129	Complete Spring bush changing	0
130	Shacker Plate/Pin changing each	47
131	Shackle Absorber Mounting chaging	47
132	Shock Absorber Bush changing	177
133	Shock Absorber changing each (front)	277
134	Shock Absorber changing each (rear)	177
135	Spring Leaf changing (each spring)	347
136	Spring rearranging	377
137	Stablizer Bush changing each	47
138	Labour Charges (Exhaust System)	0
139	Silencer Brake/Mounting changing	7
140	Silencer Box removing and refitting	47
		49989
Spare parts		237951
Services		49989
Total		287940

