

Hiace bus. Rates for 2025-2026

Sl. no	Description of Item (2)	
		Kuenzom Automobile Workshop
1	HIACE BUS	0
2	SPARE PARTS	0
3	Accelator Cable	677
4	Arm Upper	8677
5	Arm Lower	5277
6	Air filter	1997
7	Battery	8977
8	Benzer washer	147
9	Brake disc	4277
10	Brake light	2977
11	Brake Light bulb	47
12	Brake pad	14777
13	Ball Joints Upper	1977
14	Ball Joints Lower	1677
15	Break Master Cylinder	3277
16	Brake shoe	4277
17	Cluth plate	9877
18	CV Joint(R &L)	3277
19	Coolant	247
20	Diesel filter	1247
21	Distilled water	37
22	Dynamo (Alternater)	14777
23	Engine chamber	0
24	Engine mounting	1477
25	Engine Oil filter	947
26	Engine oil	407
27	Engine Oil Cap	857
28	Fan Belt	2977
29	Fog light	1877
30	Front axle (RH)	0
31	Front axle (LH)	0
32	Front beam Assembly	0
33	Front cross member	0
34	Fuel pump assembly	0
35	Fuel tank assembly	0
36	Fuel Filter(Desel Filter)	1247
37	Fuse	7



38	Gear oil	397
39	Glow Plugg/Spark Plug	2977
40	Grease Cap	77
41	Hand brake lever	1247
42	Head Gasket	3277
43	Head light	1127
44	Hood	0
45	Hub assembly	5277
46	Hub grease	0
47	Hub oil seal	477
48	Hydraulic filter	0
49	Hydraulic oil	557
50	Jack	3877
51	Lever	677
52	looking mirror	1577
53	Main Fuse	577
54	Main Beraing Oil Seal	1257
55	Mobil filter	947
56	Nut & bolt	7
57	Oil Seal	377
58	Pressure nozel	0
59	Power Stearing Oil	557
60	Power Stearing Belt	847
61	pressure plate	8777
62	Pump calibration	0
63	Relese Bearing	1877
64	Radiator assembly	16777
65	Seat assembly	0
66	Self starter	12577
67	Side light assembly	0
68	Side light bulb	47
69	Steering Arm	1477
70	Steering box assembly	9877
71	Steering Rag Assembly	18777
72	Steering pitman	1257
73	Suspension Bush Assembly	1247
74	Steering shaft	0
75	Tie rod end (LH)	1577
76	Tie rod end (RH)	1677
77	Tie rod shaft	0



78	Timing Belt	2977
79	Water gasket	257
80	Water jacket	97
81	Water separator filter	0
82	wheel bearing	1957
83	Wind Shelt Glass	13777
84	Wheel Wrench	477
85	Wiper Blade	647
86	Wheel Jack	547
87	Piston with pin	1257
88	Piston ring	1257
89	Oil Nozel	0
90	Connecting Bearing	677
91	Main Bearing	977
92	Connecting Rod	1257
93	Oil pump Assembly	0
94	Crank Shaft bearing	727
95	Valve Oil Seal	247
96	Valve Lifter Coner	147
		227635

Sl. no	Description of Services	
		Kuenzom Automobile Workshop
1	HIACE BUS	0
2	SPARE PARTS	0
3	Accelator Cable	147
4	Arm Upper	277
5	Arm Lower	277
6	Air filter	47
7	Battery	47
8	Benzer washer	47
9	Brake disc	347
10	Brake light	47
11	Brake Light bulb	47
12	Brake pad	247
13	Ball Joints Upper	377
14	Ball Joints Lower	377
15	Break Master Cylinder	377
16	Brake shoe	247
17	Cluth plate	1147



18	CV Joint(R &L)	477
19	Coolant	147
20	Diesel filter	247
21	Distilled water	7
22	Dynamo (Alternater)	677
23	Engine chamber	877
24	Engine mounting	247
25	Engine Oil filter	47
26	Engine oil	147
27	Engine Oil Cap	7
28	Fan Belt	147
29	Fog light	77
30	Front axle (RH)	477
31	Front axle (LH)	477
32	Front beam Assembly	1147
33	Front cross member	247
34	Fuel pump assembly	357
35	Fuel tank assembly	247
36	Fuel Filter(Desel Filter)	247
37	Fuse	7
38	Gear oil	147
39	Glow Plugg/Spark Plug	377
40	Grease Cap	47
41	Hand brake lever	247
42	Head Gasket	1147
43	Head light	47
44	Hood	147
45	Hub assembly	247
46	Hub grease	247
47	Hub oil seal	247
48	Hydraulic filter	247
49	Hydraulic oil	47
50	Jack	47
51	Lever	47
52	looking mirror	47
53	Main Fuse	47
54	Main Beraing Oil Seal	977
55	Mobil filter	47
56	Nut & bolt	47
57	Oil Seal	247



58	Pressure nozel	377
59	Power Stearing Oil	47
60	Power Stearing Belt	277
61	pressure plate	1147
62	Pump calibration	477
63	Relese Bearing	1147
64	Radiator assembly	447
65	Seat assembly	147
66	Self starter	247
67	Side light assembly	127
68	Side light bulb	47
69	Steering Arm	247
70	Steering box assembly	1147
71	Steering Rag Assembly	1147
72	Steering pitman	247
73	Suspension Bush Assembly	347
74	Steering shaft	247
75	Tie rod end (LH)	347
76	Tie rod end (RH)	347
77	Tie rod shaft	247
78	Timing Belt	877
79	Water gasket	47
80	Water jacket	47
81	Water separator filter	147
82	wheel bearing	377
83	Wind Shelt Glass	1977
84	Wheel Wrench	47
85	Wiper Blade	47
86	Wheel Jack	47
87	Piston with pin	377
88	Piston ring	557
89	Oil Nozel	47
90	Connecting Bearing	277
91	Main Bearing	377
92	Connecting Rod	247
93	Oil pump Assembly	147
94	Crank Shaft bearing	47
95	Valve Oil Seal	197
96	Valve Lifter Coner	147
		29908



Spare parts		227635
Services		29908
Total		257543

