


Bolero rates for 2025-2026		
SL. no	Description of Item (2)	
		Kuenzom Automobile Workshop
1	Air filter (Bolero Spare parts)	0
2	Anabond gum	97
3	Air cleaner	547
4	Accelerator cable	247
5	Bypass filter	0
6	Bendex pinion	1677
7	Battery (EXITE)	9877
8	Battery end	97
9	Brake light assy	347
10	Brake light bulb	47
11	Ball joint	1247
12	Brake oil	147
13	Brake pad	1977
14	Brake shoe	5277
15	Brake servo	147
16	Brake drum	3277
17	Brake master cylinder upper	1977
18	Brake air pipe	1247
19	Bible box	2147
20	Chira pin lock	7
21	coolant	247
22	controlling packing	97
23	controlling bolt no.14	14
24	controlling switch	377
25	Crown	0
26	Crown packing	97
27	Crown blade	0
28	Crown oil	397
29	Crown washer	47
30	Clutch plate	3277
31	Clutch cylinder	0
32	centre bolt	97
33	clutch release bearing	1477
34	cross bearing	977



35	compressor kit	1247
36	compressor packing	97
37	check nut	147
38	cycle pin	47
39	Cylinder Assy	0
40	Deisel filter	447
41	Doti	10
42	distilled water	37
43	Dianama Assy	12577
44	door handle	247
45	Engine oil	407
46	eliment kit oil filter	547
47	Excel	0
48	Fan belt	347
49	fit pump	577
50	fr.hubs oil seal inner	157
51	Fr. Hubs Oil seal outer	157
52	fr. Hubs bearing inner	1247
53	fr. Hubs bearing outer	1247
54	fr.brake linning repit	47
55	Fr.wheel bolt	147
56	Fr. And Rr.spring bush	147
57	Fr,and Rr.spring pin (plain type)	247
58	Fr.and Rr, Axel oil seal inner	247
59	Fr.and Rr, Axel oil seal outer	247
60	Fr. Wheel bearing	1247
61	Fr. shock absorber	1247
62	Fr. Bumper	2177
63	Fr. Safe guard	1277
64	Fr. Check knot	147
65	footmate	2977
66	fuse	7
67	Gear oil	397
68	Gear box oil seal	557
69	gear box shim kit	47
70	Greese	347
71	Gasket	1877
72	Hydrolic oil	577




73	Hand brake	1247
74	Hand brake servo kit	1677
75	Horse pipe assy.	1257
76	Head light assy	987
77	Head light grill	677
78	Head light bulb	147
79	Head rest	1777
80	Insulatio tape	27
81	I-bing	0
82	king pin bush	677
83	king pin	1277
84	king pin first over size	1257
85	king pin bearing upper/lower	437
86	king pin kit	127
87	Kerosene	97
88	Longitude	0
89	looking glass	347
90	Looking mirror handle	247
91	KM cable	347
92	Mobile filter	347
93	mobile chamber	1877
94	Number plate	377
95	Nozel setting	0
96	nozel pipe	677
97	nipple blade wafer	347
98	publisher	0
99	Pressure plate	3977
100	Rr. Brake lining repit	47
101	Radiator	5277
102	Radiator cap	477
103	Rr.Aux'B'leaf	1977
104	Rr. Bumper	3777
105	Rack	10
106	Rr. Hub oil seal inner	197
107	Rr. Hub oilseal outer	197
108	Rr. Wheel bearing	1267
109	Rr.shock absorber	1287
110	release bearing	1677
111	Self starter Assy	6577



112	self carbon	1677
113	self bearing	247
114	self bush	677
115	synchroniser brass ring	1257
116	shocker bush	97
117	Sylincer pipe whole set	0
118	Sylicer box	4277
119	solenoid switch	2217
120	Spring main leaf	1977
121	spring 2nd leaf	1577
122	spring 3rd leaf	1477
123	spring 4th leaf	1277
124	spring 5th leaf	1177
125	spring 6th leaf	977
126	shakle pin	247
127	Steering rack Assy	13577
128	steering cross	917
129	steering cover	847
130	spring washer	47
131	spring pin	147
132	spring bush	147
133	Spring hanger	347
134	Seat cover (best quality)	7577
135	self bush	977
136	solonite switch	5277
137	Turbo	15557
138	tyre roading	187
139	Tyre roading end	647
140	tailpinion	547
141	U bolt	477
142	vacuume pipe	977
143	vacuum brake pipe	687
144	wind shied glass	5977
145	wipper blade	547
146	wheel drum	2977
147	Water pump	2677
148	wind shield	0
149	window glass	987
150	Water jack	257



151	wheel bolt	247
		195739
Sl. no	Description of Services	
		Kuenzom Automobile Workshop
1	Air filter (Bolero Spare parts)	0
2	Anabond gum	97
3	Air cleaner	547
4	Accelerator cable	247
5	Bypass filter	7
6	Bendex pinion	677
7	Battery (EXITE)	47
8	Battery end	97
9	Brake light assy	47
10	Brake light bulb	47
11	Ball joint	677
12	Brake oil	47
13	Brake pad	247
14	Brake shoe	347
15	Brake servo	127
16	Brake drum	127
17	Brake master cylinder upper	477
18	Brake air pipe	247
19	Bible box	1147
20	Chira pin lock	7
21	coolant	47
22	controlling packing	247
23	controlling bolt no.14	247
24	controlling switch	357
25	Crown	1147
26	Crown packing	247
27	Crown blade	127
28	Crown oil	247
29	Crown washer	47
30	Clutch plate	1147
31	Clutch cylinder	117
32	centre bolt	97




33	clutch release bearing	1147
34	cross bearing	477
35	compressor kit	247
36	compressor packing	97
37	check nut	147
38	cycle pin	47
39	Cylinder Assy	247
40	Deisel filter	247
41	Doti	10
42	distilled water	37
43	Dianama Assy	677
44	door handle	147
45	Engine oil	407
46	eliment kit oil filter	247
47	Excel	677
48	Fan belt	247
49	fit pump	247
50	fr.hubs oil seal inner	347
51	Fr. Hubs Oil seal outer	347
52	fr. Hubs bearing inner	477
53	fr. Hubs bearing outer	477
54	fr.brake linning repit	47
55	Fr.wheel bolt	147
56	Fr. And Rr.spring bush	147
57	Fr,and Rr.spring pin (plain type)	247
58	Fr.and Rr, Axel oil seal inner	247
59	Fr.and Rr, Axel oil seal outer	247
60	Fr. Wheel bearing	377
61	Fr. shock absorver	247
62	Fr. Bumper	677
63	Fr. Safe guard	577
64	Fr. Check knot	147
65	footmate	47
66	fuse	7
67	Gear oil	397
68	Gear box oil seal	347
69	gear box shim kit	47
70	Greese	347



71	Gasket	1377
72	Hydrolic oil	577
73	Hand brake	677
74	Hand brake servo kit	477
75	Horse pipe assy.	257
76	Head light assy	97
77	Head light grill	157
78	Head light bulb	47
79	Head rest	677
80	Insulatio tape	47
81	I-bing	0
82	king pin bush	677
83	king pin	1277
84	king pin first over size	1277
85	king pin bearing upper/lower	437
86	king pin kit	127
87	Kerosene	97
88	Longitude	0
89	looking glass	27
90	Looking mirror handle	57
91	KM cable	247
92	Mobile filter	347
93	mobile chamber	977
94	Number plate	377
95	Nozel setting	357
96	nozel pipe	247
97	nipple blade wafer	47
98	publisher	0
99	Pressure plate	1477
100	Rr. Brake lining repit	47
101	Radiator	977
102	Radiator cap	47
103	Rr.Aux'B'leaf	677
104	Rr. Bumper	577
105	Rack	10
106	Rr. Hub oil seal inner	197
107	Rr. Hub oilseal outer	197
108	Rr. Wheel bearing	677
109	Rr.shock absorver	247



110	release bearing	1147
111	Self starter Assy	657
112	self carbon	247
113	self bearing	247
114	self bush	677
115	synchroniser brass ring	657
116	shocker bush	97
117	Sylincer pipe whole set	427
118	Sylicer box	247
119	solenoid switch	877
120	Spring main leaf	677
121	spring 2nd leaf	577
122	spring 3rd leaf	677
123	spring 4th leaf	477
124	spring 5th leaf	477
125	spring 6th leaf	477
126	shakle pin	247
127	Steering rack Assy	1677
128	steering cross	577
129	steering cover	847
130	spring washer	47
131	spring pin	147
132	spring bush	147
133	Spring hanger	347
134	Seat cover (best quality)	657
135	self bush	557
136	solonite switch	97
137	Turbo	977
138	tyre roading	187
139	Tyre roading end	647
140	tailpinion	547
141	U bolt	477
142	vacuume pipe	677
143	vacuum brake pipe	557
144	wind shied glass	2477
145	wipper blade	47
146	wheel drum	247
147	Water pump	977
148	wind shield	0



149	window glass	677
150	Water jack	124
151	wheel bolt	247
		59585
Spare parts		195739
Services		59585
Total		255324

